



Open - before opening the upper desk, fasten the fixing screw to avoid sliding sideways of the upper desk


1




2



3




4



5




6




Slide sideways in open position – when sliding the desk sideways, loosen the fixing screw before you start


7



8




9




Close - before closing the upper desk, fasten the fixing screw to avoid sliding sideways of the upper desk


1




2




3




4



5




6




Slide sideways in closed position – when sliding the desk sideways, loosen the fixing screw before you start

7



8



9

